

FIG.1




FIG.2




FIG.3




FIG.4A

FIG.4B

FIG. 5A











FIG. 5B



SELECT THE MEDIUM YOU HAVE BROUGHT IN.

 MEMORY STICK	 COMPACT FLASH	 SMART MEDIA
 FLOPPY DISK	 COMPACT DISC	 PC CARD


RETURN 

FIG.6




FIG.7

RETURN TO THE
PREVIOUS HOLDER

YOU CAN PRINT UP TO 50 IMAGES. WHEN YOU FINISH
SELECTION, CHOOSE "END OF SELECTION".

IMG0011. PCD

IMG0012. PCD

IMG0013. PCD

IMG0015. PCD

IMG0016. PCD

IMG0017. PCD

IMG0018. PCD

IMG0019. PCD

IMG0020. PCD

IMG0014. PCD

IF YOU DON'T
UNDERSTAND

BACK

NEXT


ALL
SELECTED

END OF
SELECTION

RETURN

FIG.8

○ PRINT ONE IMAGE.



SERVICE CHARGE ¥50

THE NUMBER OF PRINTS

001 PRINTS

DECREASE

TURN IMAGE

TO LEFT

SIZE ADJUSTMENT

○ NO ○

INCREASE


TO RIGHT

YES ○

END OF SETTING

○OK○

RETURN



IF YOU DON'T UNDERSTAND




FIG.9




FIG.10




FIG.11




FIG.12




FIG.13




FIG.14




FIG.15




FIG.16




FIG.17

NUMBER OF PRINTS	LL	L, 2L
1	20	20
2	20	32
3	40	32
4	40	40
5	60	60
6	60	64
7	80	64
8	80	80
9	100	100
10	100	96
11	120	100
12	120	120
13	140	128
14	140	128
15	160	140
16	160	160
17	180	160
18	180	160
19	200	180
20	200	192
21	220	192
22	220	200
23	240	220
24	240	224
25	260	224
26	260	240
27	280	260
28	280	256
29	300	260
30	300	260
31	320	288
32	320	288
33	340	300
34	340	320
35	360	320
36	360	320
37	380	340
38	380	352
39	400	352
40	400	360
41	420	380
42	420	384
43	440	384
44	440	400
45	460	420
46	460	416
47	480	420
48	480	440
49	500	448
50	500	448

FIG. 18




FIG.19

NUMBER OF PRINTS	L, L, L	L, L, 2L	L, 2L, 2L
1	20	20	20
2	20	32	32
3	20	32	32
4	40	32	40
5	40	40	32
6	40	64	40
7	60	60	60
8	60	64	64
9	60	64	64
10	80	64	64
11	80	80	64
12	80	96	80
13	100	100	96
14	100	96	96
15	100	100	100
16	120	128	96
17	120	120	100
18	120	128	120
19	140	128	128
20	140	128	128
21	140	140	140
22	160	160	128
23	160	160	140
24	160	160	160
25	180	160	160
26	180	160	160
27	180	180	160
28	200	192	160
29	200	192	180
30	200	192	192
31	220	200	192
32	220	224	200
33	220	220	192
34	240	224	200
35	240	224	220
36	240	224	224
37	260	240	224
38	260	256	224
39	260	260	224
40	280	256	240
41	280	260	256
42	280	288	256
43	300	280	260
44	300	288	256
45	300	288	260
46	320	288	280
47	320	300	288
48	320	320	288
49	340	320	300
50	340	320	288

FIG.20